

Aquavar SOLO



Variable Speed Submersible Pump Controllers for Operating 2 Wire and 3 Wire Single Phase and Three Phase, 230V, 3/4 – 5 HP Submersible Pumps 1AS15, 3AS20, 3AS30, 3AS50

Features and Benefits

- Constant Pressure Pump Control
- Controller acts as a pump protection and troubleshooting device
- Ability to retrofit with existing well system regardless of motor brand
- Pressure transducer better protected from power surges
- Uses include Residential, Irrigation and Greenhouse applications
- Optional accessories available: Gauge Guard, Float Switches, Moisture Sensor Relay and Over-Pressure Switch

Literature:

Brochures

- [BRCPVFD R1 Variable Speed Product Line](#)
- [BRCPVFDSP R1 Línea de Productos de Velocidad Variable](#)
- [BRCPVDFR R1 Gamme de produits à vitesse variable \(fr\)](#)

Technical Brochures

- [BAQSOLO R2 Aquavar SOLO Product Brochure](#)
- [BCPVFDACC R1 CentriPro Variable Speed Controller Accessories](#)
- [BGPROPAK60 Aquavar ProPak 30-60 Hz Kits](#)
- [BGPROPAK80 Aquavar ProPak 30-80 Hz Kits](#)

Installation/Operation Manuals

- [IM229 R06 Aquavar SOLO Installation Manual](#)
- [IMS SOLOQ 1 Aquavar SOLO Quick Installation Guide](#)
- [VFD Quick Start Safety Guidelines](#)
- [Obsolete-IM182 Balanced Flow Installation Manual](#)
- [BMAID R3 Motor Application and Installation Data](#)
- [IM234 R01 9K585 Moisture Sensor Relay Installation & Operation Instructions](#)

Parts Lists

- [Aquavar SOLO and Balanced Flow Repair Parts](#)

Guidelines

- [Aquavar SOLO FAQ](#)
- [IM232 Trouble Shooting Balanced Flow Drives \(OBSOLETE\)](#)
- [Obsolete-IM219 Replacement of the AB/BF/HS Pressure Transducer Cable](#)