

LIFTManager™ Plunger Lift Controller



The LIFTManager plunger lift controller is user-friendly with multi-option functionality. The “basic” unit is very easy to operate and comes configured with the control method(s) specified by the user. The system can be set up to be as simple as intermittent control or as sophisticated as an auto adjusting differential pressure control.

Modes of Operation:

- Intermittent
- Time control (on/off)
- Pressure control (2 pressures)
- Differential Pressure Control
- Auto adjust feature
- Hi/Lo option
- Basic Time Control
- Auto adjust feature
- On/Off/Afterflow
- Hi/Lo option
- Secondary pressure control for on cycle
- Single or dual valve option
- Tank wait option

Features & Benefits:

Easily installs with standard two-bolt valve bracket.

Four lines of display allows for quick collection of historical data.

- Travel time history
- Pressure history
- Current measures pressure(s)
- Calculates longest, shortest and average off time
- Valve and plunger count (intermit mode)

High/Low external pressure switch shutdown supported.

Controller program easily upgraded for individual or all control modes.

Basic time control with dual valve option can be used for intermittent gas lift / plunger lift assist applications.

User-friendly keypad.

Battery operated with solar charger option.